


2 copies (typed)

RANSU SAKU SEI KI

"RANDOM NUMBER GENERATING MACHINE"

9 7538 9503

"Don't trust machines"
"Too easy to use"



Very wide distribution - but
not in Navy/Kawabata

nickel steel

electric switch

hand switch

Prints single
digit in groups
of 4 with
space between

of Aihara used.

Keep inside
like typewriter
space keys.
[TYPE BARS]

wooden

ANGŌ KIKAI

"CIPHER MACHINE"

carriage return

Rubber cylinder

Black Bakelite

cover of keys



button Key

gray enamel

Aluminum lid

Steel cover

lacquered lines

Electric plug "on + off"

Electric switch

graduations marked.


windows graduations.

probably spacer

Typewriter tape (on top)

Pin


(60 keys)



Ango Kikan

2345035030

over 60



Hinge

Solid metal

staple

double contact

unscrew parts

Attach (with screw)

staple

Attach

staple

pin
Pliers

over 60 -
Relay
from

